



AquaForm DC1 APPLICATION MANUAL

*Caution when handling: Aluminum edges are sharp, wear gloves

1 Wipe clean wall side of flange

2 Apply a bead of sealant at each weld joint, if applicable

3 Place install tool inside of opening

4 Apply a bead of air barrier sealant to exterior face of inner wythe, around perimeter of rough opening

5 Place frame onto the arms of installation tool and shift frame to align with window opening

6 Slide frame to wall and firmly press the frame into the air barrier sealant

7 Install screws 10 inches apart around mounting flange

8 Tool any sealant that has pushed out from flange ensuring no pinholes in sealant

9 Install compatible flashing from exterior face of inner wythe and lap the flashing over the AquaForm mounting flange, terminate flashing 1 to 1.5" from finish sealant bead, apply termination bead

WARNING:

Window installer: AquaForm DC1 frame is NOT a structural support for the window assembly

DO NOT install shims between AquaForm DC1 windows

DO NOT screw into the AquaForm

Insulation installer: Please keep in mind that when using our weep system, please ensure that the insulation does not block or obstruct weeps which can prevent water from escaping the weep assembly